


6






SLC TWIN PRO¹

QUICK START GUIDE


- SLC-700-TWIN PRO2
- SLC-1000-TWIN PRO2
- SLC-1500-TWIN PRO2
- SLC-2000-TWIN PRO2
- SLC-3000-TWIN PRO2



7



DOWNLOADABLE SOFTWARE:
www.salicru.com/support



USBHID UPS



USER'S GUIDE:
www.salicru.com/support

1



SAFETY

www.salicru.com/safety


2


<p>1x</p> <p>SHUCKO VERSION</p>	<p>1x</p> <p>1x</p>	<p>1x</p> <p>1x</p>	
<p>1x</p> <p>IEC VERSION</p>	<p>1x</p> <p>1x</p>	<p>1x</p> <p>1x</p>	


3




4.0





 220V / 230V / 240V
 50 Hz / 60 Hz



4.2



4.3



5

